



Model 464 Electronic Control Unit User Guide

Solinst[®]

1.0 Introduction	1
1.1 Operating Principles	1
1.2 Model 464 Electronic Control Unit Specifications	1
1.3 Control Panel	2
1.4 LCD Display	2
2.0 Control Unit Operation	3
2.1 Start Up	3
2.1.1 Main Menu	3
2.2 LCD Contrast	4
2.3 About	4
2.4 Preset Flow Rates	4
2.5 User Flow Rates	5
2.5.1 Saved Settings	5
Edit Settings	6
Delete Settings	6
2.5.2 Create Setting	7
2.6 Automatic Drive/Vent Cycles	7
2.7 Manual Drive/Vent Cycles	8
2.8 Battery Replacement	8
3.0 Pumping Instructions	9
3.1 Preparation	9
3.2 Pumping Set Up	9
3.3 Pump Optimization	10
Bladder Pumps	10
Double Valve Pumps	10

1.0 Introduction

1.1 Operating Principles

The Model 464 Electronic Control Unit controls the supply of compressed gas to pneumatic pumps. Drive (pressure) and vent periods are cycled to provide water flow. During pressurization periods, water is forced into the sample tubing. The vent period allows water to re-enter (recharge) the pump. Cycle repetition may be controlled manually or automatically using pre-set pumping rates.



Figure 1-1 Model 464 Electronic Control Unit

1.2 Model 464 Electronic Control Unit Specifications

Model 464 Specifications	
Operating Temperature:	-20°C to 50°C
Weight:	5 lbs (2.3 Kg)
Dimensions:	9.1" x 10.2" x 4.9" (23 cm x 26 cm x 12 cm)
Drive/Vent Time Range:	1-999 seconds
Maximum Site Name Length:	16 characters (upper or lowercase and numeric)
Memory Capacity:	99 user flow rates in non-volatile FRAM, 3 preset in Flash
Battery Life:	40,000 drive/vent cycles @ 25°C from 4 AA alkaline batteries (100 hours based on 10 second drive/vent cycles)
Maximum Output Pressure:	125 psi (861 KPa)
Maximum Input Pressure:	150 psi (1034 KPa)



Note:

Pressing any key will turn the Control Unit on (except Manual Control button).



Note:


The Control Unit will turn off automatically after 5 minutes of being idle, provided that cycling is not active.




Note:

Battery Life is 40,000 drive/vent cycles or 100 hours at 10 second drive/vent cycles.

1.3 Control Panel

 **OK button:** selects a highlighted menu item (also toggles between lower and uppercase letters and pressure units). Press and hold for at least 3 seconds to turn the Control Unit off. (However, this will not work in the Contrast Menu, you can only use the left cursor key to exit the menu, and the plus/minus keys to adjust the contrast.)

 **Cursor keys:** navigate through the menus and menu items.

 **Plus/Minus keys:** cycle through numbers and letters when editing or creating new flow rates. Increase/decrease LCD display contrast. (Hold down to scroll quickly through values).

Manual Control Valve: allows manual operation of the Control Unit. When pushed the solenoid opens. See Page 8.

Air In: connection for the supply line from the compressed gas supply source. (In-line filter is not required.)

Air Out: connection for the drive line from the pump.

Regulator: sets the pumping pressure. Turn clockwise to increase the pumping pressure and counter-clockwise to decrease pressure.

Pressure Gauge: displays the pumping pressure.

Battery Enclosure: houses four (4) AA alkaline batteries.

1.4 LCD Display







Figure 1-2 Electronic Control Unit LCD Display

 **Bar icons :** indicate the amount of time remaining before the Control Unit automatically turns off. Each of the four bars represents 1 minute 15 seconds. The Control Unit will automatically turn off after 5 minutes of being idle.

 **Battery icon:** represents the battery life remaining. Battery life is also numerically displayed as a percentage to the right of the icon. The icon will flash when the battery percentage is 0.

 **Arrows:** left pointing arrow indicates there is at least one menu that can be accessed using the left cursor key. Right pointing arrow indicates a sub-menu exists for the active menu item, and can be accessed using the right cursor key or OK button (moves to next item).



Note:
The Control Unit does not come with the batteries installed.

2.0 Control Unit Operation

2.1 Start Up

Press any button on the keypad to turn the Control Unit on. When first starting the Control Unit with new batteries, or restarting after replacing the batteries, the Control Unit will perform a self-test to identify any faults that may exist. The start-up screen is shown first (Figure 2-1 Start-up Screen After Replacing Batteries); following a short pause the main menu will be displayed.



Figure 2-1 Start-up Screen After Replacing Batteries

2.1.1 Main Menu

There are four main menu items for the Electronic Control Unit (Figure 2-2).

Preset Flow Rates: allows you to select a flow rate with predefined drive and vent cycles (Low Flow, Medium Flow, or High Flow).

User Flow Rates: allows you to create user-defined flow rates, save flow rates, select and edit saved flow rates.

LCD Contrast: enables you to adjust the brightness of the display.

About: will display information about the Control Unit, including firmware version and Solinst contact information.



Note:
Turning the Control Unit on, displays the last screen shown at the time of shut-down.




Figure 2-2 Model 464 Main Menu

2.2 LCD Contrast

To adjust the contrast of the LCD display, use the   keys.




Figure 2-3 LCD Contrast

2.3 About

Selecting this menu item will display information about the Model 464 Control Unit, including the installed firmware version.



Figure 2-4 About

2.4 Preset Flow Rates

Preset Flow Rates have predefined drive and vent times, they cannot be edited or changed. There are three Preset Flow Rates:

PRESET FLOW RATES		
Flow	Drive	Vent
Low	50 s	25 s
Med	10 s	8 s
High	3 s	3 s




Figure 2-5 Preset Flow Rate Menu




Figure 2-6 Low Flow Rate Menu

When “Start” is highlighted, pressing OK will start the pumping cycle. When the Control Unit is running the LCD will display the progress of the vent and drive periods. Pressing the OK button when in running mode will stop the cycle.




Figure 2-7 Running Mode



Note:

The Electronic Control Unit can store up to 99 saved User Flow Rates. User Flow Rates are saved to a non-volatile memory so that they will be retained if the batteries are removed.

2.5 User Flow Rates

This menu allows you to select saved flow rates or create new flow rates.




Figure 2-8 User Flow Rates Menu

2.5.1 Saved Settings

Selecting “Saved Settings” will display a list of all previously created user-defined flow rates (Figure 2-9 User Defined Saved Settings). Use the cursor keys to navigate through the settings. To rearrange the order of the sites, use the '+' key to move the highlighted setting up one position and the '-' key to move the highlighted setting down one position.





Figure 2-9 User Defined Saved Settings

Delete Settings

To delete the setting, use the left arrow key to highlight the delete icon  and press OK. After pressing OK, a prompt will be displayed to confirm the deletion.




Figure 2-10 Delete Saved Settings



Note:

The maximum drive/vent time is 999 seconds each and the maximum pressure setting is 125 psi (861 KPa).



Note:

The displayed pressure does not control the actual pressure, it is only a reminder of the required output pressure for that site.



Note:

- 1 psi = 2.3 ft of water
- 1 KPa = 0.1 m of water

Edit Settings

Select a particular setting by pressing the right arrow or OK.




Figure 2-11 Saved Setting Information




Figure 2-12 Editing Saved Setting Information

To edit site information, use the cursor keys to navigate the fields and modify them using the +/- keys. Holding the +/- keys will cycle through letters and numbers quickly. The OK button toggles between upper and lower case letters. The "Site" field has a fixed length of 16 characters.

Use the +/- keys to change the drive and vent times. The maximum drive/vent time is 999 seconds (16.65 minutes).

Use the +/- keys to change the pressure setting. The maximum pressure is 125 psi (861 KPa). Pressing OK toggles between psi and KPa. The pressure is automatically converted to the new units. The displayed pressure does not control the actual pressure, it is only a reminder of the pressure to adjust externally.

When finished editing the site settings, use the cursor key to select "Save Changes" or "Start" to start pumping without saving the changes. When "Stop" is selected, a display will appear asking if you would like to save changes. User settings are saved to non-volatile memory so that they will be retained if the batteries are removed. A maximum of 99 user settings are supported.

2.5.2 Create Setting

To create a new setting, select “Create Setting” from the User Flow Rates menu. Enter the new site name, drive/vent times, and pressure setting using the cursor keys and +/- keys (see Edit Settings Section). Once you are finished programming the settings, use the cursor key to highlight “Save” and press OK.




Figure 2-13 Creating a New Site

2.6 Automatic Drive/Vent Cycles

Select the desired setting. To start the drive/vent cycles, use the cursor key to highlight “Start” and press OK. When the Control Unit is running, the LCD will display the progress of the vent and drive cycles. Pressing the OK button when in running mode will stop the drive/vent cycles.

**Note:**

While the drive/vent cycles are in progress it is not possible to edit the displayed site information or exit the site menu. The only option is to push OK, to stop the cycling.




Figure 2-14 Running Mode



Note:

The maximum output pressure of the Electronic Control Unit is 125 psi.

2.7 Manual Drive/Vent Cycles

The 464 Electronic Control Unit can also be operated manually if preferred. It provides an alternative if the battery power runs out.

To operate the Control Unit manually, set up and connect the pump, Control Unit and compressed gas supply (see Section 3.2 Pumping Set Up). Apply the compressed gas to the Control Unit.

Use the Regulator on the Control Unit to decrease or increase the pumping pressure. To create a drive/vent cycle, use the Manual Control Button on the Control Panel. When the Manual Control Button is pushed in, it opens the solenoid, which allows the compressed gas to be applied to the pump. When the button is released, it allows the unit to vent.



Figure 2-15 Model 464 Control Panel

2.8 Battery Replacement



Note:

The “Battery Low!” warning will appear at about 0% battery level. This is a conservative battery level estimation based on normal operation.




Figure 2-16 Low Battery Warning

If the battery level is low, the battery warning will be displayed after attempting to start a drive/vent cycle (Figure 2-16). The battery icon will also be flashing. Press OK to clear the warning message. It will not be possible to start the vent/drive cycling with a low battery. Replace the battery or operate the Control Unit manually using the Manual Control Button to continue (see Section 2.7 Manual Drive/Vent Cycles).



Note:

Always follow local health and safety practices. Work safely!



Note:

Keep Control Unit physically higher than the sample discharge and wellhead.



Note:

While the drive/vent cycles are in progress it is not possible to edit the displayed site information or exit the site menu when using a Saved Setting.



Note:

The Control Unit will turn off after five minutes of being idle, provided the Unit is not cycling. To turn the Unit off, hold down the OK button for at least 3 seconds.

3.0 Pumping Instructions

3.1 Preparation

- The Control Unit is shipped without the batteries in the housing. Install these before operating the unit. The Control Unit uses four (4) AA alkaline batteries.
- Do not let water get inside the Control Unit. Always position the Control Unit physically higher than the sample discharge and wellhead. This helps avoid the siphoning effect, where gravity back-flow of sample water can enter the Control Unit and cause damage.
- Do not release any pressure from the compressed gas supply until all preparatory steps are complete.




Figure 3-1 Pumping Set Up

3.2 Pumping Set Up

1. Connect the Supply Line to the Air In fitting on the Control Unit. Attach the other end to the compressed gas supply source.
2. Ensure your pump is installed to the desired pumping depth with the sample and drive tubing properly connected.
3. Connect the Drive Line from the Air Out fitting to the quick connect on the wellhead manifold (or air supply connection on a reel).
4. Press any button on the keypad to turn the Control Unit on.
5. Select the desired pumping settings.
6. Set the compressed gas supply regulator to no more than 150 psi.
7. Start the selected drive/vent cycle.
8. Allow several cycles for water to reach the surface, then adjust the settings as necessary.

3.3 Pump Optimization

Bladder Pumps

- Select and start your desired flow rate from the User Flow Rates menu.
- If higher flow rate is required, stop the drive/vent cycle to allow editing of the set up. Increase the drive time to increase the flow rate.
- If increasing the drive time no longer increases the flow rate, increase the vent time, then re-adjust the drive time to obtain the highest flow rate.

Double Valve Pumps

- Select and start your desired flow rate from the User Flow Rates menu.
- If a higher flow rate is required, stop the drive/vent cycle to allow editing of the set up. Slowly increase the drive time to increase the flow rate.
- If air is expelled, decrease the drive time.
- To further optimize the flow rate, increase or decrease the vent time until the highest flow rate is achieved.

Once optimization has been done, remember to save the settings for subsequent sampling events.

High Quality Groundwater & Surface Water Monitoring Instrumentation

Solinst[®]

*Solinst Canada Ltd. Todd Road, Georgetown, ON L7G 4R8
Tel: +1 (905)873-2255; (800) 661-2023 Fax: +1 (905) 873-1992; (800)516-9081
E-mail: instruments@solinst.com*

www.solinst.com