

Overview

The Levellogger Direct Read to Optical Adaptor is designed to be used in place of a Direct Read Cable, when the extra cable length is not required. This allows it to be used for multiple communication or deployment purposes. The Adaptor can be used to connect your Levellogger to a Levellogger App Interface, DataGrabber, an SDI-12 Interface Cable, PC Interface Cable, or deploy a Barologger inside an STS enclosure.



Levellogger Direct Read to Optical Adaptor

Levellogger App Interface



DataGrabber



STS Reader Cable



PC Interface Cable



SDI-12 Interface Cable

